

T2 Install & Operation Manual

Safety

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

The unit should be isolated from the electricity supply before removal of any covers. Great care must be employed when working with high pressure carbon dioxide, and in no cases should the maximum operating pressure of 0.4MPa (4 bar) be exceeded.

- The appliance is not suitable for installation in an area where a water jet could be used.
- The appliance has to be placed in a horizontal position.

WARNING: Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.

WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

This appliance is intended to be used in household and similar applications such as:-


- Staff kitchen areas in shops, offices and other working environments
- Farm houses and by clients in hotels, motels and other residential type environments
- Bed and breakfast type environments
- Catering and similar non-retail applications

A-weighted emission sound pressure level is below 70 dB(A)



R290 is a refrigerant-grade propane used on a wide range of commercial refrigeration and air conditioning units. A highly pure propane, it has a low environmental impact and nominal global warming potential (GWP), meaning it possesses no qualities that can destroy the ozone layer. R290 also is the preferred hydrocarbon alternative of the Environmental Protection Agency (EPA), substituting more harmful fluorocarbon refrigerants like R22, R134a, R404a and R502.

Units with R290 can only be maintained and repaired by authorized technicians who are properly trained and certified.



- Always place the dispenser in its vertical position, on a surface which can capably support its weight.
- During use this machine must remain in its upright position.
- Adequate ventilation must be allowed for – we recommend using the supplied ventilation ducting kit.
- Keep the machine away from sunlight, heat and moisture.
- Power and water supply points must be available near the dispenser, and must meet the criteria specified in the 'Specification' section of this manual.
- The environment where this machine is installed must be free of dust and corrosive/explosive gases.

Waste Electrical Products:

- The WEEE symbol indicates that this item contains electronic components which must be collected and disposed of separately.
- Never dispose of electrical waste in general municipal waste. Collect and dispose of such waste separately.
- Make use of the return and collection systems available to you, or your local recycling programme. Contact your local authority or place of purchase to find out what schemes are available.
- Electrical and electronic equipment contains hazardous substances which, when disposed of incorrectly, may leak into the ground. This can contribute to soil and water pollution which is hazardous to human health; and endangers wildlife.
- It is essential that consumers look to re-use or recycle electrical or electronic waste to avoid it going to landfill sites or incineration without treatment.




COOLING SYSTEM	Stainless steel direct chill coil encased in a solid-block system for instant response cool down action. Ultra efficiency compression system with capillary control. Environmentally friendly R290 refrigerant.
COLD TEMPERATURE	2°C - 11°C.
OUTPUT PER HOUR (ProCore)	50 litres Chilled 50 litres Sparkling
OUTPUT PER HOUR (ProCore+)	80 litres Chilled 80 litres Sparkling
DISPENSE	Quadra Neck Faucet with ergonomically designed and situated light touch sensitive controls.
MAXIMUM RUNNING POWER CONSUMPTION - CHILLED & AMBIENT	ProCore 0.14kW - 230V ProCore+ 0.21kW - 230V
MAXIMUM RUNNING POWER CONSUMPTION - CHILLED, AMBIENT & SPARKLING	ProCore 0.2kW - 230V ProCore+ 0.26kW - 230V
QUANTITY OF REFRIGERATION GAS	ProCore R290a 33g ProCore+ R290a 40g
POWER SUPPLY	220V - 240V AC (50 Hz)
WATER CONNECTION	Mains in - 3/4" BSP
CO2 CONNECTION	1/4" Push Fit.
DIMENSIONS	(w x d x h) 320 x 370 x 340mm.
WEIGHT	27Kg MAX
RATED CURRENT - CHILLED & AMBIENT	ProCore 1.0A ProCore+ 1.45A
RATED CURRENT - CHILLED, AMBIENT & SPARKLING	ProCore 1.2A ProCore+ 1.7A
FUSE RATING	5A
MINIMUM TO MAXIMUM INLET WATER PRESSURE	0.05MPa (0.5 bar) - 1.0 MPa (10 bar) Internally regulated to 0.3 MPa (3 bar)
CO2 PRESSURE	0.4MPa (4 Bar) Maximum
MINIMUM TO MAXIMUM AMBIENT ROOM OPERATING TEMPERATURE	5°C - 35°C
CLIMATIC CLASS	N

Model Overview

Introduction

The T2 & T2+ epitomises cutting-edge design and innovation with its contoured tap and compact ProCore unit. This is our most discreet range and will fit into any environment seamlessly.

The ProCore dispenser is a cooler designed to provide chilled and carbonated water. All the materials and components are tested during the entire production process in order to satisfy all expectations.




Component/Feature Overview

T2 Tap - Major Components

Contents:

- | | |
|--------------------------------------|-----------------------|
| 1 no T2 | 1 no Connector Cable |
| 1 no Top Plate with Control Panel | 1 no Waste Drain Pipe |
| 1 no Drip Tray | 1 no Fixings Set |
| 1 no 1.0m x 6mm Insulated Water Pipe | |




1. Faucet, 2. Main body, 3. Top Mounting Plate, 4. Drip tray, 5. Capacitive touch display, 6. Connector Cable

ProCore Electronic - Major Components

Contents:

- 1 no Undercounter Unit
- 1 no 2.0m Power Cord Set

- 1 no Co2 Regulator with Gauge & Connection tube*
- 1 no ProCore Simple-fit Ventilation Kit




1. ProCore Simple-fit Chimney, 2. ProCore Simple-fit Base, 3. Front Panel, 4. Carry Handle, 5. Top Panel, 6. Water Outlet, 7. Water Inlet, 8. Tap Connection, 9. CO2 Inlet*, 10. On/Off Switch, 11. Power Connection, 12. Side Panel

Please Note:

Mains Installation Kit & Filters are supplied as extra items according to individual ordering requirement.

*Sparkling versions only

Dimensions



Installation

Installation Requirements

Identify a suitable location for the ProCore unit. It should be positioned within 1.0m of the faucet, and within 2.0m of suitable services connections. Allow enough space to fit the ventilation ducting system.


The ProCore unit must be installed in accordance with the relevant requirements of:


- The appropriate building regulations by application of either The Building Regulations (England and Wales), The Building Regulations (Scotland) or The Building Regulations (Northern Ireland). In territories other than those listed the local regulations in force must be complied with.
- The Water Supply (Water Fittings) Regulations (England, Wales and Northern Ireland) or The Water Byelaws in Scotland.

The unit must not be installed where it is liable to freeze. If the unit is thought to be frozen it must not be switched on. It should be allowed to thaw and must then be thoroughly inspected to ensure it is undamaged.


Service Requirements

- Water: Mains potable water – internally regulated to 0.3MPa (3 bar)
- CO2: Food Grade CO2 to be supplied
- Min mains pressure 0.05MPa (0.5 bar)
- Electricity: 5A supply – Earth Leakage Protected
- Waste Drain Connection







First, install the T2 tap to the top plate base. Line up the tap so it's parallel to the front of the base.




Insert the tap so the fixing screws line up with the indentations. Tighten up the M4 hex screws with an Allen key until the tap is secure.




Using the M6 allthreads as provided locate them into the base of the tap and tighten till secure using the flange nuts provided.




When planning and providing for the connection to the services, always allow for easily accessible service isolator fittings and for the position of an external water filter.




Identify a suitable position for the faucet. Refer to the cut out guide template. Ensure worktop is level to allow system to drain.




Also allow for the height of the swan neck under any overhanging cupboard/shelf.




Allow for the space needed for forming the required cut out. Relate the selected position to the underneath of the counter and check for any obstructions.



Allow sufficient space for fitting the worktop fixing brackets.




Tighten the 4 fixing flange nuts so that the worktop brackets are fixed up against the underside of the worktop.



Fit waste pipe and secure with jubilee clip. Connect to drain ensuring there is a constant fall.

Operation

Tap Control Panel



1. Chilled Dispense, 2. Sparkling Dispense, 3. Ambient Dispense,
4. 'eco' Mode Symbol 5. Warning Symbol.

Basic Functions

Dispensing from unit:

Press and hold dispense icon and release to finish dispense

- Chilled icon flashing – Unit is chilling down
- Sparkling icon flashing – Tank is refilling

'eco' Mode:

'eco' mode symbol illuminates when unit is in 'eco' mode, to awaken unit press and hold any dispense icon. The ProCore will activate 'eco' mode in the below instances

Dispense inactivity
Low room light level

Warning Symbol


'Warning triangle' symbol will illuminate and flash upon a fault. The number of flashes can relate to a particular fault. [Click to view fault codes](#)

Ventilation System Installation


When Borg & Overström undercounter units are installed inside a cabinet or housing, adequate ventilation is recommended to ensure that they operate satisfactorily. During a cooling cycle it is normal for the unit to produce heat, and the purpose of ventilation is to provide a supply of air that can absorb the generated heat which would otherwise accumulate inside the cabinet or housing, and reduce the cooling performance of the unit. The amount

of heat generated by the cooling cycle depends directly upon the amount of usage – the higher the usage, the more heat produced. To provide adequate ventilation we recommend that air grilles/vents are fitted as supplied (or vent apertures formed) in the cabinet to allow an airflow as shown below. Normally this should be enough for all situations.


Important: Before making any cuts into the cupboard or kick board, ensure the area to be cut is free from water pipes or electrical cables. There is a risk of serious injury or death if electrical cables are cut, and significant damage to property if a water pipe is cut.




Using the template provided, carefully mark and cut the aperture to the edge of the cabinet.




Situate the ProCore Simple-fit ventilation base in place centrally over the aperture. Ensuring that there is a minimum of 30mm air gap to each side.




Insert 4 screws into the holes located. Do not overtighten at this stage.




Place the rear vent chimney over the 4 screws and slide downwards into place.




Tighten all 4 fixing screws.



Lift and tilt the unit into position ready to lower.




Lower the appliance carefully into position on the ventilation base to ensure the chimney is located correctly in the chimney aperture at the rear of the base.




After installation the vents at the front of the cabinet and to the sides of the ventilation base must not be obstructed.

NOTE: Any obstructions will adversely affect the airflow to the appliance causing potential for poor performance, over heating or fridge failure.


ProCore Installation & Water Connection




Locate the ProCore in a suitable position, using the supplied ventilation base by following the instructions above.




Connect the T2 tap to the water outlet.




Connect the T2 Tap USB to the ProCore unit.




Connect the Water Inlet adapter as supplied and connect to water supply.




Connect the CO2 supply from gas regulator, ensuring the pressure is set to max 58 PSI (4 bar), and turn on the supply (See CO2 Installation section)




Connect the chiller to the electricity supply.



The carbonator should be purged of air by activating the sparkling water dispense for approximately 10 seconds.




Turn on the water supply to fill the tank.




Allow the machine to stand for 8 - 12 minutes for the initial chilling process to complete.


CO2 Bottle Installation - Sparkling Versions Only




1 Unpack CO2 Regulator and fit elbow fitting to spigot outlet.




2 Attach the regulator to the disposable CO2 bottle, ensuring the small pressure relief vent in the stem is facing away from you or anyone else. Ensure the regulator is closed. Hand tighten securely.



3 Connect the assembled CO2 bottle and regulator to the CO2 inlet using a 1/4" pipe.




4 Stand the cylinder in a suitable place.




5 We recommend between 3.5 - 4 bar (58 PSI) (max). Do not exceed 4 bar pressure.

Sparkling Water Flow Rate - Sparkling Versions Only


NOTE: Sparkling water flow rate factory setting = 2.4L per minute MAX. This may need adjusting depending on inlet pressure. To do so follow below steps:



Remove the 2 screws holding the unit lid down and slide the lid off.



Locate the flow control adjuster, this can be found towards the front of the unit.




Using a M6 hex key flow can then be adjusted as follows: turn the hex key anti-clockwise to increase flow and clockwise to restrict flow. After each adjustment the flow rate should be timed to an acceptable flow rate and/or uninterrupted sparkling dispense

Once the correct flow rate is achieved place the cover back on to the unit by sliding it in place and replacing the screws.

Maintenance & Cleaning

Sanitisation Guide

NOTE: Failure to use sanitising products and processes approved by Borg & Overström will invalidate your warranty.





Please note that this sanitisation fluid contains an active caustic/alkaline agent. Always use responsibly and with care remembering that due to its alkaline nature unnecessary concentrated/prolonged contact with any materials, including metals, can cause damage. Always rinse all contact surfaces after use with clean water.




Avoid skin contact and wear protective gloves when handling sanitisation fluids.




In the event of any skin contact, flush immediately with clean, cold water.


Emptying the CO2 Tank




Turn off the water supply.



Press and hold the Sparkling water dispense button until all the water is expelled and only CO2 gas is being released.



The tank is empty of sparkling water when only CO2 is being released.



Ensure to release the Sparkling water button and take care to avoid releasing excess amounts of CO2 gas as this may damage the tank.

Advanced Troubleshooting

Fault Diagnostics

Problem/Report	Possible Cause	Suggested Action
No Water Dispensing	Water Pressure Regulator	Check water flow through the regulator. Replace if necessary.
	Check Tap HMI Control	Check fault codes.
No Sparkling Water	No CO2 pressure	Check CO2 bottle, regulator and non-return valve. Supply pressure should be 58 psi (4bar), replace as necessary.
	Carbonator Tank Not Filling	Check carbonator probe for possible short circuit to ground. Check for pump timeout, cycle power off & on then purge carbonator.
	Water isolated from machine	Check water inlet supply.
Poor Quality Carbonation	Incorrect CO2 Pressure	Check CO2 bottle, regulator and non-return valve. Supply pressure should be 58 psi (4bar), replace as necessary.
	Air in Carbonator Tank	Visit to view steps for purging tank.
	Residue in Carbonator Tank	After prolonged use, a surface film can develop within the carbonator tank. Refer to cleaning and sanitising instructions.
Warm Drinks	Insufficient cooling air flow through the fridge.	Check that the condenser is not blocked. Check supply to cooling fans (230V AC). If supply present replace fans. If supply not present move on to the compressor. The supply to the fans and the compressor are linked.
	Compressor not running	Check supply to compressor (230V AC). Check NTC probe is not faulty Check for system over heat. Allow the unit to cool and check for airflow obstructions. Once the unit has cooled the fridge system will restart. If the problem persists contact technical support.
	Fridge failure (See fault codes)	If compressor & fan are running and there is no cooling contact technical support.

Fault Codes

Internal overheat activated



Compressor timing out too often




Water not filling carbonator tank




T2/T2+ Chilled & Ambient Circuit Schematic







T2/T2+ Chilled, Ambient & Sparkling Circuit Schematic




Water Pathway - Chilled & Ambient



Water Pathway - Chilled & Sparkling




Water Pathway - Chilled, Ambient & Sparkling




Spares

ProCore/ProCore+ Exploded Parts Diagram





T2/T2+ Exploded Parts Diagram



Spares List

Part No.	Description	CA	CS	CSA
720130	Main Control PCBA	•	•	•
700721	Top Panel Asm	•	•	•
720117	Right Panel Asm	•	•	•
720113	Left Panel Asm	•	•	•
720045	Front Panel Asm	•	•	•
701537	Pump	•	•	•
700085	Cooling Fan	•	•	•
701343	UV Asm	•	•	•
700922	Flow Switch	•	•	•
701596	UV Control Board	•	•	•

Part No.	Description	CA	CS	CSA
701094	3/4" BSP Inlet Solenoid	•	•	•
462325	1/4" Bulkhead Connector		•	•
462850	6mm Bulkhead Connector	•	•	•
701076	8mm PRV - ProCore+	•	•	•
701515	6mm 2 Way Solenoid	•	•	
701525	6mm 3 Way Solenoid			•
462858	6mm Stem Elbow	•	•	•
462859	8mm Stem Elbow	•	•	•
462869	8mm Equal Elbow	•	•	•
462360	8mm Equal Tee	•	•	•
462375	5/16" - 1/4" Elbow		•	•
462851	8>6mm Straight Reducer	•	•	•
462857	8>6mm Reducing Elbow		•	•
701263	6mm Compensator		•	•
462667	8mm Safety Check Valve		•	•
462668	1/4" Safety Check Valve		•	•

Part No.	Description	CA	CS	CSA
700092	Laminar Flow Outlet	•	•	•
720112	Tap Outlet Polished Metal	•	•	•
701453	Tap Outlet Plated Black	•	•	•
720193	Cup Stand Plated Black	•	•	•
720152	Cup Stand Plated Metal	•	•	•
720289	T2 CSA HMI Lens Asm			•
720292	T2 CS HMI Lens Asm		•	
720295	T2 CA HMI Lens Asm	•		

